



## Ford Focus Fuel Door Installation Guide

### Step 1 - Gather required tools.

Please gather the following tools before you begin the installation:

- \* Power Drill
- \* 3/16 drill bit.
- \* 9mm or 11/32 open ended wrench.
- \* 9/64" Hex Key or Allen Head wrench
- \* Flat file for filing metal.
- \* Rasp file or round file.
- \* Fine permanent marker.
- \* Phillips screw driver.
- \* Utility Knife.
- \* Duct Tape
- \* Pliers.
- \* Small piece of cloth.
- \* Zip tie - medium size.
- \* Body color touch up paint.

### Step 2 - Unpack fuel door kit and verify contents.

Check items you removed from the box. You should have the following before beginning:

- \* Aluminum Fuel Door
- \* (3) Stainless steel 9/64" hex socket bolts with (3) washers and (3) lock nuts.
- \* Printed instruction manual.



### Step 3 - Clean working area.

A. Carefully clean area in and around the fuel door. You will be taping area to keep from scratching it during the installation so this area must be clean.

